

materialised

FABRIC CARE, CLEANING & MAINTENANCE

MAT 110

BLEACH CLEANABLE TEXTILE UPHOLSTERY



Regular maintenance & prompt cleaning of stains is recommended. Check cleaning solution on an inconspicuous area first.

1. Protect from sunlight & vacuum regularly
2. Blot off liquid soiling
3. Remove bulky matter with a flat blade
4. Brush off/vacuum loose particles
5. Prepare a neutral pH detergent solution (10:450ml) or use pre-prepared Crypton Care Gold and/or Purple
6. Gently rub the solution onto the soiled area with a soft brush
7. Rinse detergent off with clean water and a soft white cloth & allow to air dry

For stubborn stains a mild solution of Isopropyl Alcohol may be used - then repeat steps 1-7

Bleach cleanable 1:10 bleach/water ratio

Do not use solvent based cleaners & ensure all detergent residue is completely rinsed off.



Scan this QR code to watch a short "how to" video (available in multiple languages) or find it at:
materialised.com/resources/cleaning-and-care

FAILURE TO ADHERE TO THESE CLEANING GUIDELINES MAY VOID YOUR WARRANTY.

We love to help! Contact us for more info & cleaning advice. **+61 2 8558 3500** | **materialised.com**